



Nº: 957.06

PARL 04/25

CE UK CA

2023/1542 EU, N° 41:
battery@paulmann.de

Li-Ion

230 000 046










1x

1x

1x

Incl.

Tools: screwdriver, drill, screwdriver



i **Solar Charging** > 8 hours

i **USB Charging** 5V --- 2A > 8 hours

i **100%** > 4 hours

H

i **Click** **On/Off**

i **>5s** **Factory Reset**

Reset with app			
Delete from		Flash → On Connection Mode ⌚ 3min.	

>5s		Flash → On → Connection Mode ⌚ 3min.	
---	---	--	---

TOUCH LINK

<30cm

Remote Control
N°: 500.67

Prestitemp

Flash → On
Connection Mode

3min.

2,4 GHz – 2,4835 GHz

Fréquence radio [2,4 GHz - 2,4835 GHz] Puissance de radiofréquence transmise [10 mW]

1	or Factory reset		Connection Mode 3min.
----------	--	---	--

3		 Flash → On	
---	--	---	---

[illegible]




3 2x Flash → On

 = **FR** Les piles et accumulateurs usagés, ainsi que les lampes qui peuvent être retirées de l'appareil usagé sans être détruites, doivent être séparés de l'appareil usagé avant d'être remis à un point de collecte. Les distributeurs sont tenus de reprendre gratuitement ce produit dans le cadre de l'article 17, paragraphes 1 et 2 de l'ElektroG. Les utilisateurs finaux d'équipements usagés doivent veiller, sous leur propre responsabilité, à la suppression des données à caractère personnel sur les équipements usagés à mettre au rebut.

 www.paulmann.com




A diagram showing a 'Router' connected to a 'Zigbee 3.0 Gateway'. The Router is represented by a rounded rectangle with two vertical lines above it and three dots to its right. The Zigbee 3.0 Gateway is a square device with a zigzag antenna symbol above it. A horizontal line connects the Router to the Gateway.



 **DE Nur wiederaufladbare Batterien verwenden**
EN Only use rechargeable
FR N'utiliser que des piles rechargeables
 5x Li-Ion Battery (3,7V 2600mAh)