HotAir Nozzles

Overview

Weller

#PowerfulTogether

WXHotAir

900 W Controlled High Power Rework Module 900 W, 230 V
Order No. T0053175699

NQ Nozzles

- For WXHotAir, WHA3000P/V
- 4 sides heated
- Integrated pre-heating plate for pre-heating components
- Air outlet slots around the plate with a width of approx. 1 mm

Article Model Order No.	Length in mm	Width in mm
NQ05 T0058736839N	10.7	10.7
NQ15 T0058736838N	14.5	10.0
NQ10 T0058736818N	14.8	14.8
NQ20 T0058736837N	15.5	13.0
NQ25 T0058736814N	18	18
NQ30 T0058750721N	17.5	23.5
NQ35 T0058736807N	20,5	20,5
NQ T0058736880N	24	12
NQ40 T0058736804N	26	26
NQ45 T0058736833N	31.3	31.3
NQ50 T0058736891N	36	36
NQ55 T0058736890N	43	43

NQT Nozzles

- For WXHotAir, WHA3000P/V
- 4 sides heated without protruding edge for thin components
- Air outlet slots around the plate with a width of approx. 1 mm

NQT10 T0058750741N	14.8	14.8
NQT25 T0058750742N	18	18
NQT T0058750739N	22	22

Measuring Nozzle

- For WXHotAir, WHA3000P/V

NA 20 T0058736875N	

ND Nozzles

- For WXHotAir, WHA3000P/V
- 2 sides heated
- Integrated pre-heating for pre-heating components
- Air outlet slots around the plate with a width of approx. 1 mm

Article Model Order No.	Length in mm	Width in mm
ND05 T0058736843N	10.7	10.7
ND10 T0058736842N	14	10
ND15 T0058736841N	19	14
ND20 T0058736840N	21.5	14.8

NRV Nozzles

- For WXHotAir, WHA3000P/V
- Integrated pre-heating plate for pre-heating components
- Air outlet slots around he plate with a width of approx. 1 mm

NRV07 T0058750770N	7
NRV10 T0058750772N	10
NRV12 T0058750774N	12

NR Nozzles

- For WXHotAir, WHA3000P/V
- Round nozzles, without vacuum
- Bent versions available

Article Model Order No.	Diameter in mm	Angle
NR04 T0058736881N	2.5	
NR05 T0058736867N	4	
NR10 T0058736870N	7	
NR02 T0058736882N	1.7	45°
NR06 T0058750765N	6	45°

DR Nozzles

- For WXHotAir, WHA3000P/V
- Hot air dual nozzle, round, without vacuum

DR05 T0058736883N	2 x 2.5

TNR Nozzles

- For WXHotAir (Adapter) and WTHA1
- Round nozzles, without vacuum

Article Model Order No.	Diameter in mm	Angle
TNR 25 T0058768742N	2.5	
TNR 40 T0058768743N	4	
TNR 70 T0058768744N	7	
TNRB 17 T0058768745N	1.7	45°
TNRB 60 T0058768746N	6	45°

Accessories

WXHotAir Nozzle Adapter T0058774706	for TNR nozzles
Nozzle Change Tool T0051504999N	for NR, ND, NQ
Heating Plate WHP3000, 1200 W T0053364699N	
PCB board holder WBHS T0053316599N	
Vacuum Pick-Up WVP T0052918499N	
WRK Reflow Set T0051515599N	
ADAPTER CABLE USB A/ M~RS232 TO RJ12 T0058774721	
Thermocouple Type K T0058755782	Ø 0.1 mm
Thermocouple Type K T0053119099	Ø 0.5 mm
1 Step Foot Switch T0051312099N	
WSR212 Safety Rest for WXHotAir T0051518699	

Depositing Rack for NR, ND, NQ Nozzles

Designed for up to six hot-air nozzles, it allows for quick and safe nozzle changes even when the nozzles are hot. The nozzle remains in the holder while the hot-air piston is simply moved to another nozzle. This minimizes the risk of burns to both the user and the material.

Depositing Rack T0051504899N	Up to 6 nozzles

Find out more about Weller WXHotAir

weller-tools.com