# Programming Quick Guide
-LS6300J

Installation

Make sure that the scanner has the correct cable to plug into PC as below described,

After you plug cable into PC and hear the beep sound, the scanner can read the barcodes now.

Connect With PC

Reset Configuration to Default :

(For USB HID)

If you are unsure of the scanner configuration or have scanned the incorrect codes, please scan the following barcode. This will reset the scanner to its factory defaults.

USB HID

‖‖‖‖‖‖‖‖‖‖‖‖

Keyboard Country (FOR USB HID Only)

Scan the appropriate country code as below to program the keyboard layout for your country or language. As a general rule, the following characters are supported, but need special care for countries other than the United States: @ | $ # { } [ ] = / ` \ < > ~

‖‖‖‖‖‖‖‖‖‖‖‖ | ‖‖‖‖‖‖‖‖‖‖‖‖
USA (Default setting) | France

‖‖‖‖‖‖‖‖‖‖‖‖ | ‖‖‖‖‖‖‖‖‖‖‖‖
Italy | Spanish

‖‖‖‖‖‖‖‖‖‖‖‖ | ‖‖‖‖‖‖‖‖‖‖‖‖
Portuguese (Brazil) | Portuguese (Portugal)

‖‖‖‖‖‖‖‖‖‖‖‖ | ‖‖‖‖‖‖‖‖‖‖‖‖
German | Finnish

‖‖‖‖‖‖‖‖‖‖‖‖ | ‖‖‖‖‖‖‖‖‖‖‖‖
Polish (Programmers) | Polish (214)

‖‖‖‖‖‖‖‖‖‖‖‖ | ‖‖‖‖‖‖‖‖‖‖‖‖
Czech (QWERTZ) | Dutch (Netherlands)

Ending character Setting

‖‖‖‖‖‖‖‖‖‖‖‖ | ‖‖‖‖‖‖‖‖‖‖‖‖
Cancel ending character | Enter

‖‖‖‖‖‖‖‖‖‖‖‖
Tab

1D Symbologies – 1

CODABAR

ENABLE ‖‖‖‖‖‖‖‖‖‖‖‖ | DISABLE ‖‖‖‖‖‖‖‖‖‖‖‖

CODE 39

ENABLE ‖‖‖‖‖‖‖‖‖‖‖‖ | DISABLE ‖‖‖‖‖‖‖‖‖‖‖‖

Interleaved 25

ENABLE ‖‖‖‖‖‖‖‖‖‖‖‖ | DISABLE ‖‖‖‖‖‖‖‖‖‖‖‖

Industrial 25

ENABLE ‖‖‖‖‖‖‖‖‖‖‖‖ | DISABLE ‖‖‖‖‖‖‖‖‖‖‖‖

ISSN

ENABLE ‖‖‖‖‖‖‖‖‖‖‖‖ | DISABLE ‖‖‖‖‖‖‖‖‖‖‖‖

GS1 DataBar

ENABLE ‖‖‖‖‖‖‖‖‖‖‖‖ | DISABLE ‖‖‖‖‖‖‖‖‖‖‖‖

GS1 Databar Limited

ENABLE ‖‖‖‖‖‖‖‖‖‖‖‖ | DISABLE ‖‖‖‖‖‖‖‖‖‖‖‖

GS1 Databar Expanded

ENABLE ‖‖‖‖‖‖‖‖‖‖‖‖ | DISABLE ‖‖‖‖‖‖‖‖‖‖‖‖

1D Symbologies – 2

Matrix 25
ENABLE   DISABLE

CODE 93
ENABLE   DISABLE

CODE 128
ENABLE   DISABLE

GS1-128
ENABLE   DISABLE

UPC-A
ENABLE   DISABLE

UPC-E
ENABLE   DISABLE

EAN 8
ENABLE   DISABLE

EAN 13
ENABLE   DISABLE

ISBN
ENABLE   DISABLE

2D Symbologies

PDF 417
ENABLE   DISABLE

QR Code
ENABLE   DISABLE

Micro QR Code
ENABLE   DISABLE

Data Matrix
ENABLE   DISABLE

Aztec Code
ENABLE   DISABLE

How to take out the USB cable

1. Please insert a thin object (e.g. a bent paper clip) into the release hole.
2. Then, pull out the USB cable

Release Hole

- Information in this document is subject to change without notice.

Q180515_01