Read the manual carefully before use, and retain it for future reference.

Product Overview

Thank you for choosing this high-capacity power bank that uses high-quality lithium-ion batteries and a charging and discharging chip with excellent performance in safety, efficiency, and compatibility.

Notes:
The battery level check button is not a power button. The power bank automatically detects charging and discharging requirements and activates the corresponding port. The power bank has no standby mode.

Safety: The power bank is provided with multiple safeguarding technologies to prevent overcharge, over-discharge, overheating, and short circuits in any working condition.

Efficiency: The power bank supports USB-C PD 3.0 and USB-A SCP 5A fast charging. This mode can be used to charge low-current devices such as Bluetooth headphones and smart watches. When charging a mobile phone, it can also be used to indicate the power bank's current discharge mode. Simply press the button again to exit this mode. The power bank automatically exits this mode after 30 seconds.

Charging

Connect a USB-A power adapter to the power bank via the USB-C port or the integrated USB-C cable to charge the power bank. The indicator will flash following the rules below:

Battery Level	LED1	LED2	LED3	LED4
0%-25%	Slowly Off	Off	Off	Off
25%-50%	On	Slowly Off	Off	Off
50%-75%	On	On	Slowly Off	Off
75%-99%	On	On	On	Slowly Off
100%	On	On	On	On

Discharging

Press power bank uses the USB-A ports for charging other devices. The indicator shows the power bank's current level:

Battery Level	LED1	LED2	LED3	LED4
Discharge/Idle	On	On	On	On
0-25%	Blinking	Off	Off	Off
25%-50%	On	Blinking	Off	Off
50%-75%	On	On	Blinking	Off
75%-100%	On	On	On	Blinking

Low-current discharge: When the power bank is not charging, press the button to activate the indicator light. The light will turn off after 30 seconds.

⚠WARNINGS

- The battery pack subjected to extremely low or pressure during use, storage, or transportation may cause leakage of flammable liquids or gases.
- Do not dispose of batteries as household waste. Dispose of them safely as per local regulations.

Precautions

- Please fully charge the power bank on its first use.
- Use an appropriate charger and USB cable (brand-brand products) as recommended to charge the power bank and prevent damage to the charger.
- Do not reverse the power bank unattended when it is being charged or using it to charge other devices. Unplug the charger and charging cable after the power bank is fully charged or when not in use for long periods.
- Once the power bank is fully charged or charges another device in full, unplug the charging cable in time to avoid power consumption and potential risks.
- If the battery pack heats up, swells, or leaks during use, stop using it immediately and contact the manufacturer or a professional repair center.
- Do not place the battery in a microwave oven or pressure vessel. Do not short-circuit or pierce the battery or electrical circuit. If this happens, stop using the power bank immediately, and contact the manufacturer.
- When you notice the battery has swelled, deformed, leaked, or smell a strange, pungent, or irritating odor, immediately stop using it and contact the manufacturer.
- Do not place the battery in a high-temperature environment. Do not place it near heat sources, such as in the pocket of your clothes, in a hot car, or near a heater. Ensure the power bank is not covered by clothing, pillows, bedding, or other insulating materials during use, charging, or storage. Do not place the battery in a high-temperature environment for extended periods. Do not stack them together to ensure better heat dissipation.
- Do not place the battery in a low-temperature environment. Low temperatures may affect the battery's performance and its efficiency, freezes, or an environment with an ambient temperature below 0°C may cause the battery to malfunction. Do not place the battery in a cold environment for extended periods.
- Do not place the battery in a high-pressure environment. Do not place it in a pressure chamber or underwater.
- Do not expose the battery to prolonged vibrations, bumps, or impacts, or continuously bend, twist, or fold it.
- Do not place the battery in an environment with a strong electromagnetic field.
- Do not replace the battery by yourself. Replacing the battery with the wrong type may result in a failure of safety protection, causing an explosion or fire.

Specifications

Model: P52ZM	Battery Type: Lithium-ion battery
Cell Capacity: 10000 mAh / 37 Wh	
Charging port: USB-C/Integrated USB-C Cable	
Output Port: USB-A/USB-C/Integrated USB-C Cable	
USB-C: 5V⎓3A, 9V⎓3A, 9V⎓2.22A, 12V⎓2.25A, 20V⎓1.85A	
USB-A: 5V⎓3A, 9V⎓2.22A, 12V⎓1.85A	
Output: 22.5 W Max. Multi-port: 5 W	
Input: USB-C: 5V⎓3A, 9V⎓3A, 9V⎓2.22A, 12V⎓2.25A, 20V⎓1.85A; USB-A: 5V⎓3A, 9V⎓2.22A, 9V⎓1.67A, 12V⎓1.25A	
Operating Temperature: 5 °C to 35 °C	
Storage Temperature: -10 °C to 45 °C	
Charging Time:	
Approx. 3.5 hours (using a 9 V/2.22 A, 12 V/1.5 A charger* and the USB-C cable included)	
Approx. 5.5 hours (using a 5 V/2 A charger* and the USB-C cable included)	
*Charger not provided with power bank	

EU Declaration of Conformity

Hereby, Xiaomi EU declares that this equipment is in compliance with the applicable directive and other relevant provisions. The full text of the EU declaration of conformity is available at the following Internet address:
http://www.xiaomi.com/global/support/declaration/mi

WEEE Information

Do not dispose of this product as ordinary household waste. Dispose of this product according to your local laws and regulations. When this product reaches its end of life, contact your local authorities for information on the correct way to dispose of this product. The correct disposal of this product will save valuable resources and prevent any potential future negative effects on human health and the environment caused by improper waste disposal. Improper handling of this product will result in penalties according to local laws and regulations.

Manufacturer: Xiaomi Communications Co., Ltd.
Address: #019, 9th Floor, Building 6, 33 Xi'erqi Middle Road, Haidian District, Beijing, China, 100085
For further information, please go to www.mi.com
User Manual Version: V1.0

XIAOMI Power Bank 10000mAh
Integrated Cable User Manual
Power Bank 10000mAh Integriertes Kabel Bedienungsanleitung
Power bank Xiaomi 10000mAh Integrated Cable
Manuel d'utilisation du Xiaomi Power Bank 10000mAh Integrated Cable
Manual de usuario de Xiaomi Power Bank 10000mAh Integrated Cable
Руководство пользователя внешнего аккумулятора Xiaomi Power Bank 10000мАч Integrated Cable
Power bank Xiaomi 10000mAh Entregre Kablolu Kullanım Kılavuzu
Xiaomi Powerbank 10000mAh Integrated Cable User Manual
Manual del usuario de la Batería portátil Xiaomi 10000 mAh (cable integrado)

Charge en cours

Connecter un adaptateur secteur Xiaomi à la batterie externe via le port USB-C, ou utiliser le câble USB-C intégré pour la batterie externe. L'indicateur affiche les règles suivantes pendant la charge :

Niveau de batterie	LED1	LED2	LED3	LED4
0 à 25 %	Clignote	Éteint	Éteint	Éteint
25 à 50 %	Allumé	Clignote	Éteint	Éteint
50 à 75 %	Allumé	Allumé	Clignote	Éteint
75 à 99 %	Allumé	Allumé	Allumé	Clignote
100 %	Allumé	Allumé	Allumé	Allumé

Décharge en cours

La batterie externe alimente un port USB-A pour charger d'autres appareils. L'indicateur affiche les conditions de décharge :

Niveau de batterie	LED1	LED2	LED3	LED4
Veille/Décharge	Allumé	Allumé	Allumé	Allumé
0 à 25 %	Clignote	Éteint	Éteint	Éteint
25 à 50 %	Allumé	Clignote	Éteint	Éteint
50 à 75 %	Allumé	Allumé	Clignote	Éteint
75 à 100 %	Allumé	Allumé	Allumé	Clignote

Décharge à faible courant : Appuyez sur le bouton pour activer le voyant. Le voyant s'éteint au bout de 30 secondes.

⚠AVERTISSEMENTS

- Une utilisation incorrecte peut entraîner une panne de la batterie, une surchauffe, voire un incendie ou une explosion. Ne pas démonter ni modifier la batterie ou la coque. Ne pas utiliser d'objets pointus ou d'outils pour percer, frapper ou écraser la batterie. Ne pas exposer la batterie à des liquides.
- Cette batterie externe n'est pas un jouet. Veuillez la garder hors de portée des enfants et des animaux. Ne laissez pas les enfants jouer avec cette batterie externe sans supervision.
- Ne pas exposer la batterie à des températures élevées, telles que des sources de chaleur, des rayons du soleil, des feux ou des chocs. Ne pas la placer dans un four, un micro-ondes ou un équipement sous pression. Ne pas la placer dans un environnement à haute pression, comme une chambre à pression ou sous l'eau.
- Ne pas exposer la batterie à des vibrations prolongées, à des chocs ou à des impacts, ni la plier, la tordre ou la tordre en continu.
- Ne pas utiliser la batterie dans un environnement présentant un champ électrique ou magnétique puissant.
- Ne pas remplacer la batterie par vous-même. Le remplacement par un modèle incorrect peut entraîner la défaillance du système de sécurité, et par conséquent, un incendie ou une explosion.
- Si la batterie gonfle, se déforme, fuit ou dégage une odeur étrange, piquante ou irritante, cessez immédiatement d'utiliser la batterie et contactez le fabricant ou un centre de réparation professionnel.
- Ne placez pas la batterie dans un four à micro-ondes ou un récipient sous pression. Ne court-circuitez pas la batterie ou le circuit électrique et ne percez pas la batterie ou le circuit électrique. Si vous constatez un tel incident, cessez immédiatement d'utiliser la batterie externe et contactez le fabricant.
- Si vous constatez que la batterie est gonflée, déformée, fuit ou dégage une odeur étrange, piquante ou irritante, cessez immédiatement d'utiliser la batterie et contactez le fabricant.
- Ne placez pas la batterie dans un environnement à haute température. Ne la placez pas à proximité de sources de chaleur, telles que la poche de votre vêtement, une voiture chaude ou un radiateur. Veillez à ne pas couvrir la batterie externe avec des vêtements, des oreillers, des draps ou d'autres matériaux isolants pendant l'utilisation, la charge ou le stockage. Ne laissez pas la batterie dans un environnement à haute température pendant des périodes prolongées. Ne les empilez pas les uns sur les autres pour une meilleure dissipation de la chaleur.
- Ne laissez pas la batterie dans un environnement à basse température. Les basses températures peuvent affecter les performances et l'efficacité de la batterie, provoquer un gel, ou une température ambiante inférieure à 0 °C peut entraîner un dysfonctionnement de la batterie. Ne laissez pas la batterie dans un environnement froid pendant des périodes prolongées.
- Ne placez pas la batterie dans un environnement à haute pression. Ne la placez pas dans une chambre de pression ou sous l'eau.
- Ne exposez pas la batterie à des vibrations prolongées, à des chocs ou à des impacts, ni la pliez, la tordre ou la tordre en continu.
- Ne placez pas la batterie dans un environnement présentant un champ électromagnétique puissant.
- Ne remplacez pas la batterie par vous-même. Le remplacement par un modèle incorrect peut entraîner la défaillance du système de sécurité, et par conséquent, un incendie ou une explosion.
- Si la batterie gonfle, se déforme, fuit ou dégage une odeur étrange, piquante ou irritante, cessez immédiatement d'utiliser la batterie et contactez le fabricant ou un centre de réparation professionnel.
- Ne placez pas la batterie externe