Please read this manual carefully before using the product and keep it properly.

Product Overview

Thank you for choosing Xiaomi 33W Power Bank 20000mAh (Black). This power bank is equipped with two USB-A ports and supports 33 W two-way fast charging and 33 W fast charging for Xiaomi phones that support fast charging. It features a durable and lightweight design, a 20000 mAh capacity, and a high-efficiency performance in superior series, offering a reliable and convenient experience.

The battery level, max flow rate, and other power bank information can be viewed in the Mi Home app.

The battery level indicator flashes red when a fault occurs. The power bank detects charging and discharging automatically.

Safety: The power bank is designed based on multi-layer safeguarding technologies to prevent issues such as overheating, overcharging, overdrawing, and short circuits.

Illustrations of product and accessories in the user manual are for reference purposes only. Actual product and functions may vary due to product enhancements.

Charging

The power bank supports smart temperature control. If you charge your phone while using the power bank, the temperature during fast charging it may reach a temperature sensitive zone2. Therefore, it is recommended to continuously charge your phone for no more than 30 minutes at a time to prevent the discharging power.

If the power bank is hot, it will automatically stop to charge the phone. Wait for the power bank to cool down, then connect your phone to charge. If the power bank is not hot, it will resume charging. The charging status is not affected by the temperature. The battery level indicators flash red if the power bank is hot.

Discharging

The power bank uses a USB-A port to discharge. The power bank supports 33 W two-way fast charging and 33 W fast charging for Xiaomi phones that support fast charging. The power bank automatically adjusts the output power based on the battery level and the connected device. The power bank will automatically stop to discharge if the battery level is too low. The power bank will automatically resume discharging when the battery level is restored to a normal level. If the power bank is hot, it may be because the power bank is in high-power discharging. If the power bank is hot, it will stop discharging. Wait for the power bank to cool down, then connect your phone to discharge. The power bank will automatically resume discharging if the temperature returns to a normal level. The battery level indicators flash red if the power bank is hot.

Battery Level	LED1	LED2	LED3	LED4
75%–100%	Blinking	On	On	On
50%–75%	Blinking	Blinking	On	On
25%–50%	Blinking	Blinking	Blinking	On
0%–25%	Blinking	Blinking	Blinking	Blinking

Output: 33 W Max. Multi-port: 5 V⎓3 A, 9 V⎓3.67 A, 11 V⎓3 A, 12 V⎓2.75 A, 20 V⎓2.25 A, 5 V⎓3 A, 9 V⎓3.67 A, 11 V⎓3 A, 12 V⎓2.75 A, 20 V⎓2.25 A (USB-A ports) 5 V⎓3 A, 9 V⎓3 A, 12 V⎓2.25 A, 20 V⎓1.65 A (USB-C ports)

Input: 5 V⎓2 A, 9 V⎓2 A, 12 V⎓1.5 A, 20 V⎓1.35 A

Non-Dimensional: 127 × 50 × 30.5 mm

Weight: 356 g

Battery capacity: 20000 mAh (3.7 V⎓)

Precautions

- Please fully charge the power bank on its first use.
- Do not charge the power bank with a low-power charger.
- Do not use the power bank to charge electronic devices.
- When the power bank will not be used for an extended period, it is recommended to charge it to a power level of about 50%. For long-term storage, do not fully charge or discharge the power bank. Charge the battery from empty to full once every 6 months.
- Do not disassemble, crush, squeeze, puncture, short circuit the power bank, or place it in a microwave oven or high-voltage device. Do not place the power bank in environments with an ambient temperature higher than 60°C (140°F). In hot weather, do not leave the power bank in a car or other hot environments. Do not use the power bank in a damp environment. Keep the power bank in a cool, dry place. Do not use the power bank if it is damaged, deformed, or has a battery leakage or odor. Do not let children or pets bite or suck the power bank. Do not use the power bank if it is damaged or has a battery leakage or odor. Do not let children or pets bite or suck the power bank. Do not use the power bank in the following situations: Charging electronic devices that are damaged, deformed, or have a battery leakage or odor; Charging electronic devices that are not designed for charging; Charging electronic devices that are not designed for charging with the power bank; Charging electronic devices that are not designed for charging with the power bank at the same time. Do not use the power bank in the following situations: Charging electronic devices that are damaged, deformed, or have a battery leakage or odor; Charging electronic devices that are not designed for charging; Charging electronic devices that are not designed for charging with the power bank; Charging electronic devices that are not designed for charging with the power bank at the same time.

WARNINGS

Improper use may result in battery failure, overheating, or fire. Please read the following warnings and use the product safely and properly. Xiaomi does not and cannot be responsible for any damage or injury caused by improper use or use in accordance with the following requirements.

- Do not expose the power bank to pressure, impact, strong vibration, or high temperature. Do not place the power bank in a short circuit or cause damage to the battery or electrical circuits. Stop using the power bank immediately if it is damaged.
- When the power bank becomes swollen, deformed, short-circuited, or, in its capacity is significantly reduced, please stop using it and contact the Xiaomi Service Center.
- If the battery leakage occurs, please keep it away from fire. Leakage or fire hazard may occur. If the power bank is hot, it may be because the power bank is in high-power discharging. If the power bank is hot, it will stop discharging. Wait for the power bank to cool down, then connect your phone to charge. Do not use the power bank to charge electronic devices. If the power bank is hot, it may be because the battery level is low. Do not use the power bank to charge electronic devices. Wait for the power bank to cool down, then connect your phone to charge. If the power bank will automatically resume charging if the temperature returns to a normal level.
- Do not use the power bank in a damp environment. Keep the power bank in a cool, dry place. Do not place the power bank in environments with an ambient temperature higher than 60°C (140°F). In hot weather, do not leave the power bank in a car or other hot environments. Do not place the power bank in a microwave oven or high-voltage device.
- Do not let children or pets bite or suck the power bank. Do not place the power bank in a place where children or pets can easily reach. Do not let children or pets bite or suck the power bank. Do not let children or pets bite or suck the power bank.
- Do not use the power bank in the following situations: Charging electronic devices that are damaged, deformed, or have a battery leakage or odor; Charging electronic devices that are not designed for charging; Charging electronic devices that are not designed for charging with the power bank; Charging electronic devices that are not designed for charging with the power bank at the same time. Do not use the power bank in the following situations: Charging electronic devices that are damaged, deformed, or have a battery leakage or odor; Charging electronic devices that are not designed for charging; Charging electronic devices that are not designed for charging with the power bank; Charging electronic devices that are not designed for charging with the power bank at the same time.

EU Declaration of Conformity

The manufacturer hereby declares that this product complies with the essential requirements and other relevant provisions of the Directives and Regulations. The full text of the EU declaration of conformity is available at the following Internet address: http://www.mi.com/global/support/declaration/en

WEEE Information

All products bearing this symbol are waste electrical and electronic equipment (WEEE) and should be disposed of in accordance with the European Union (EU) household waste. Instead, you should protect human health and the environment by handing over the waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment. For more information, please contact the authorities. Correct disposal and recycling of WEEE helps prevent potential negative consequences for the environment and human health. Please Contact the authorities for more information on the correct disposal of WEEE and the available as well as terms and conditions of such collection points.

Manufactured by: Xiaomi Communications Co., Ltd.
Address: 4639, 9th Floor, Building 6, 33 Xibeiwang Middle Road, Haidian District, Beijing, China, 100085
Tel: +86-400-100-5678 Website: www.mi.com
Other Manual Version: V1.0

EU REP
Xiaomi Technology Netherlands B.V.
Room 33 M Rembrandt, 2003 cmAmsterdam, Kadaster Bedemptungsnummer : 39
Hetnaste Jacob Haarst 2003 cmAmsterdam, Kadaster Bedemptungsnummer : 39
Manufacturer: Xiaomi Communications Co., Ltd.
Address: 4639, 9th Floor, Building 6, 33 Xibeiwang Middle Road, Haidian District, Beijing, China, 100085