SHELLY MOBILE APPLICATION FOR Download on the App Store Google Play EXPLORE IT ON App Gallery App Gallery

Introduction

Shelly devices can be controlled and managed directly in the local network or by using the Shelly cloud service accessible via the Internet

Download the Shelly Cloud Application by scanning the QR code above, or access the devices through the Embedded web interface, explained further down in the user guide.

Shelly devices are compatible with Amazon Echo and Google Home supported functionalities. See details at https://shelly.cloud/compatibility/.

Registration

The first time you load the Shelly Cloud mobile app, you have to create an account which can manage all your Shelly devices. You need to use an actual e-mail because that e-mail will be used in case of a forgotten password!

Forgotten password

In case you forget or lose your password, click the "Forgot Password?" link on the login screen and type the e-mail you used in your registration. You will receive an e-mail with a link to a page where you can reset your password. The link is unique and can be used only once.

ATTENTION! If you are unable to reset your password, you have to reset your device (as explained in "Device Inclusion" section, Step 1).

First steps

After registering, create your first room (or rooms), where you are going to add and use your Shelly devices. Shelly Cloud allows you to create scenes for automatic control of devices at predefined hours or based on other parameters like temperature, humidity, light, etc. (with available sensors in Shelly Cloud). Shelly Cloud allows easy control and monitoring using a mobile phone, a tablet, or a PC. Shelly Pro 2 can be grouped with other devices in the application, as well as be set to trigger actions on other Shelly devices. Setting parameters for lights, controlling blinds, etc., is also supported.



Device inclusion

Step 1

When the installation of Shelly is done and the power is on, Shelly will create its own Wi-Fi Access Point (AP).

<u>AWARNING!</u> In case the device has not created its own AP Wi-Fi network with SSID like ShellyPro2-F008D1DB58A0, please check if the device is connected according to the User and Safety Guide, Installation Instructions. If you still do not see an active Wi-Fi network with SSID like ShellyPro2-F008D1DB58A0, or you want to add the device to another Wi-Fi network, reset the device. If the

device has been powered on, you have to restart it by powering it off and then again on. After that you have one minute to press 5 consecutive times the button/switch connected to the SW terminal. You should hear the relay trigger itself. After the trigger sound, Shelly Pro 2 will return to AP mode. If not, please repeat or contact our customer support at: support@shellv.cloud.

Step 2

Please keep in mind that Shelly devices' inclusion is different on iOS and Android devices.

1. iOS inclusion - On your iOS device, open the Settings menu > WLAN and connect to the Wi-Fi network created by your Shelly device, i.e. ShellyPro2-F008D1DB58A0 (fig. 1). Open your Shelly app again and type in your home Wi-Fi credentials (fig. 2).





2. Android inclusion - From the hamburger menu on the main screen of your Shelly App choose "Add device". Then choose your home network and type in your password (fig. 3). After that, pick the Shelly device you want to include. The name of the device will be similar to: ShellyPro2-F008D1DB58A0 (fig. 4).





Step 3

Approximately 30 sec. after discovering any new devices on the local Wi-Fi network, a list will be displayed in the "Discovered Devices" room by default.



Step 4

Select "Discovered devices" and choose the device you want to include in your account.



Step 5

Enter a name for the device (in the "Device Name" field). Choose a "Room" where the device will be positioned and controlled from. You can choose an icon or add a picture to make it easier to recognize. Press "Save device".



Step 6

To control Shelly devices only through the local network, press "No".



Device settings

After your Shelly device is added in the application, you can control it, change its settings, and automate the way it works.

To switch the device on and off, use the ON/OFF button. For device management, simply click on the device's name. From there you may control the device, as well as edit its appearance and settlings.

Timer

Allows you to manage the power supply automatically. You may

- Auto ON: After turning off, the relay output will be automatically turned on after a predefined time (in seconds).
- Auto OFF: After turning on, the relay output will be automatically turned off after a predefined time (in seconds).

Schedule

This function requires a working connection to the Internet. Shelly may turn on/off automatically at a predefined time and day throughout the week. Additionally, Shelly may turn on/off automatically at sunrise/sunset, or at a specified time before or after sunrise/sunset. You may add up to 20 weekly schedules.

Internet

Configure Wi-Fi, AP, Cloud, Bluetooth, MQTT settings.

- Wi-Fi Mode Client: Connect the relay to your Wi-Fi network.
 Here, you can also set a static IP address.
- Wi-Fi Client Backup: An option to connect to an alternative network in case the primary network fails or is too slow.
- Wi-Fi Mode AP: The mode in which the device creates its own Wi-Fi connection point with the respective name (SSID).
- Ethernet: Connect the Shelly device to a network using an ethernet cable. This requires a device reboot! Here, you can also set a static IP address.
- Cloud: Connection to the cloud allows you to control your device remotely and to receive notifications and updates.
- · Bluetooth: Enable/disable
- MQTT: Configure the Shelly device to communicate over MQTT.

Application Settings

- · Channel Name: Set a name for the chosen channel
- Appliance Type: Choose from a given list what type of appliances your Shelly Pro 2 will be used with. The available options are "Socket, Lights, Heating, Entertainment". A custom type can be set as well.
- PIN lock: Restrict control of the Shelly device through the web interface by setting a PIN code. Click "Enable" and set the channel PIN lock, then click "Save".
- Exclude from Event Log: Do not show events from this device in the app.

Webhooks

Use events to trigger http endpoints. You can add up to 20 webhooks.

Share

Share the control of your device with other users.

Settings

• Button Type: These settings define the way the attached switch or button controls the output state. The possible input modes are "button" and "switch", and the relay mode can be cho-

sen depending on the preffered usage of the device.

- Invert Switch: When the input is on, the output is off and when the input is off, the output is on. For the change to be applied, the physical switch has to be toggled once after 'invert' is set to 'true'.
- Firmware version: Shows your current firmware version. If a newer version is available, you can update your Shelly device by clicking Undate.
- Geo Location And Time Zone: Set your time zone and geo-location manually or enable/disable automatic detection.
- · Device Reboot: Reboot your Shelly Pro 2.
- Factory Reset: Remove Shelly Pro 2 from your account and return it to its factory settings.
- Device Information: Here you can view the ID, IP and other settings of your device. Upon clicking "Edit device", you can change the room, name or image of the device.

THE EMBEDDED WEB INTERFACE

Shelly can be set and controlled through a web browser.

Abbreviations used

- Shelly ID the unique name of the device. It consists of 12 hexadecimal characters, the base MAC address of the device. It may include numbers and letters, for example F008D1DB58A0.
- SSID the name of the Wi-Fi network, created by the device, for example ShellyPro2-F008D1DB58A0.
- Access Point (AP) the mode in which the device creates its own Wi-Fi connection point with the respective name (SSID).
- Wi-Fi the mode in which the device is connected to another Wi-Fi network.

Initial inclusion

Step 1

Install Shelly following the connection diagrams described in the instructions included with the device, and place it into the junction box. After turning the power on, Shelly will create its own Wi-Fi network (AP).

<u>\(\mathbb{W}\) WARNING!</u> If you don't see the AP, please follow step 1 from the "Device Inclusion" section of this guide.

Step 2

Shelly Pro 2 has created its own Wi-Fi network (AP), with name (SSID) such as **ShellyPro2-F008D1DB58A0**. Connect to it with your phone, a tablet, or a PC.

Step 3

Type 192.168.33.1 into the address field of your browser to load the web interface of Shelly.

General - Home page

This is the home page of the embedded web interface. If it has been set up correctly, you will see information about the state of the two switches (ON/OFF) and common functionality menus. For individual functionality menus, choose one of the two channels

Channel settings

Click on "Channel Settings". The general settings about the channel will be displayed here. You can configure I/O settings, channel's state, channel's name, etc.

- Input/output settings input mode and relay type define the
 way the attached switch or button controls the output state. The
 possible input modes are "button" and "switch", and the relay
 mode can be chosen depending on the preffered usage of the
 device. "Set relay power on default" allows you to choose the
 default state of the relay when power is on.
- Invert Switch: When the input is on, the output is off and when the input is off, the output is on. For the change to be applied, the physical switch has to be toggled once after 'invert' is set
- · Channel Name: Set a name for the chosen channel
- PIN lock Restrict control of the Shelly device through the web interface by setting a PIN code. After typing the details in the respective fields, press "Restrict Shelly".

Timers

Allows you to manage the power supply automatically. You may

- Auto ON: After turning off, the relay output will be automatically turned on after a predefined time (in seconds).
- Auto OFF: After turning on, the relay output will be automatically turned off after a predefined time (in seconds).

hedules

This function requires a working connection to the Internet. Shelly may turn on/off automatically at a predefined time and day throughout the week. Additionally, Shelly may turn on/off automatically at sunrise/sunset, or at a specified time before or after sunrise/sunset. You may add up to 20 weekly schedules.

Webhooks

Use events to trigger http endpoints. You can add up to 20 webhooks.

Device

Get information about your device's firmware version and location. Perform reboot and factory reset. Set your time zone and geo-location manually, or enable/disable automatic detection.

• Authentication - you can set credentials to lock your device or change already existing credentials.

Networks

Configure Wi-Fi, AP, Cloud, Bluetooth, MQTT settings.