

Operating Instructions

Battery-operated Outdoor LED Star

Item no: 2574832





1 Intended use

The product is a decorative light.

The product is not suitable for domestic lighting.

The product has an IP44 ingress protection rating. It is splash proof and suitable for outdoor use. Do not submerge in water.

If you use the product for purposes other than those described, the product may be damaged.

Improper use can result in short circuits, fires, or other hazards.

The product complies with the statutory national and European requirements.

For safety and approval purposes, you must not rebuild and/or modify the product.

Read the operating instructions carefully and store them in a safe place. Make this product available to third parties only together with the operating instructions.

All company names and product names are trademarks of their respective owners. All rights reserved.

2 Delivery contents

3x LED Star

- Operating instructions
- 3x Ground spike

3 Latest product information

Download the latest product information at www.conrad.com/downloads or scan the QR code shown. Follow the instructions on the website.

4 Description of symbols

The following symbols are on the product/appliance or are used in the text:



The symbol warns of hazards that can lead to personal injury.



Read the operating instructions carefully.



This product is constructed according to protection class III.

5 Safety instructions



Read the operating instructions carefully and especially observe the safety information. If you do not follow the safety instructions and information on proper handling, we assume no liability for any resulting personal injury or damage to property. Such cases will invalidate the warranty/guarantee.

5.1 General

- The product is not a toy. Keep it out of the reach of children and pets.
- Do not leave packaging material lying around carelessly. This may become dangerous playing material for children.
- If you have questions which remain unanswered by this information product, contact our technical support service or other technical personnel.
- Maintenance, modifications and repairs must only be completed by a technician or an authorised repair centre.

5.2 Handling

 Handle the product carefully. Jolts, impacts or a fall even from a low height can damage the product.

5.3 Operating environment

- Do not place the product under any mechanical stress.
- Protect the appliance from extreme temperatures, strong jolts, flammable gases, steam and solvents.
- Protect the product from direct sunlight.

5.4 Operation

- Lights become hot. Risk of fire! Remove from packaging before operating. Fully lay lights out and install before operating.
- Consult an expert when in doubt about the operation, safety or connection of the product.
- If it is no longer possible to operate the product safely, take it out of operation and protect it from any accidental use. DO NOT attempt to repair the product yourself. Safe operation can no longer be guaranteed if the product:
 - is visibly damaged,
 - is no longer working properly,

5.5 (Rechargeable) Batteries

Correct polarity must be observed while inserting (rechargeable) batteries.

has been stored for extended periods in poor ambient conditions or
 has been subjected to any serious transport-related stresses.

- The (rechargeable) batteries should be removed from the device if it is not used for a long period of time to avoid damage through leaking. Leaking or damaged (rechargeable) batteries might cause acid burns when in contact with skin, therefore use suitable protective gloves to handle corrupted (rechargeable) batteries.
- (Rechargeable) batteries must be kept out of reach of children. Do not leave (rechargeable) batteries lying around, as there is risk, that children or pets swallow them.
- All (rechargeable) batteries should be replaced at the same time. Mixing old and new (rechargeable) batteries in the device can lead to (rechargeable) battery leakage and device damage.
- (Rechargeable) batteries must not be dismantled, short-circuited or thrown into fire.
 Never recharge non-rechargeable batteries. There is a risk of explosion!

5.6 LED light

- Do not look directly into the LED light!
- Do not look into the beam directly or with optical instruments!

6 Getting started

6.1 Securing in the ground

After selecting a suitable location, secure the product in the ground.

- 1. Attach the ground spike to the base of the product.
- 2. Firmly hold the ground spike and insert it into the ground.
- 3. Check if the product secured. If not, find a more suitable location.

6.2 Installing batteries

Note:

If an insulating strip protrudes from the battery compartment, batteries are installed already. Pull the strip out to establish the power supply.

Preconditions:

- Prepare the required number of batteries of the correct type as stated in the section "Technical data".
- 1. Unlock the battery compartment cover and open the battery compartment.
- 2. Insert the batteries into the battery compartment observing the polarity markings in the compartment.
- 3. Close and lock the battery compartment cover.

7 Operating the lights

Push the power button on the battery compartment to activate different operating modes and to switch the lights off.

| Mode indication | Description |
|-----------------|--|
| TIMER | Continous timer mode: |
| | Lights will be on for 6 hours and then off for 18 hours. This cycle continous until you select a different mode. |
| ON | Continous on mode: |
| | Lights will be on until manually switched off. |
| OFF | Off mode: |
| | Lights are off. Use this mode to permanently switch the lights off. |

Press the power button to switch modes according to the following sequence: TIMER →
ON → OFF

8 Cleaning and care

Important:

- Do not use aggressive cleaning agents, rubbing alcohol or other chemical solutions.
 They damage the housing and can cause the product to malfunction.
- Do not immerse the product in water.
- 1. Clean the product with a dry, fibre-free cloth.

9 Disposal

9.1 Product



This symbol must appear on any electrical and electronic equipment placed on the EU market. This symbol indicates that this device should not be disposed of as unsorted municipal waste at the end of its service life.

Owners of WEEE (Waste from Electrical and Electronic Equipment) shall dispose of it separately from unsorted municipal waste. Spent batteries and accumulators, which are not enclosed by the WEEE, as well as lamps that can be removed from the WEEE in a non-destructive manner, must be removed by end users from the WEEE in a non-destructive manner before it is handed over to a collection point.

Distributors of electrical and electronic equipment are legally obliged to provide free takeback of waste. Conrad provides the following return options **free of charge** (more details on our website):

- in our Conrad offices
- at the Conrad collection points
- at the collection points of public waste management authorities or the collection points set up by manufacturers or distributors within the meaning of the ElektroG

End users are responsible for deleting personal data from the WEEE to be disposed of.

It should be noted that different obligations about the return or recycling of WEEE may apply in countries outside of Germany.

9.2 (Rechargeable) batteries

Remove batteries/rechargeable batteries, if any, and dispose of them separately from the product. According to the Battery Directive, end users are legally obliged to return all spent batteries/rechargeable batteries; they must not be disposed of in the normal household waste



Batteries/rechargeable batteries containing hazardous substances are labelled with this symbol to indicate that disposal in household waste is forbidden. The abbreviations for heavy metals in batteries are: Cd = Cadmium, Hg = Mercury, Pb = Lead (name on (rechargeable) batteries, e.g. below the trash icon on the left)

Used (rechargeable) batteries can be returned to collection points in your municipality, our stores or wherever (rechargeable) batteries are sold. You thus fulfil your statutory obligations and contribute to environmental protection.

Batteries/rechargeable batteries that are disposed of should be protected against short circuit and their exposed terminals should be covered completely with insulating tape before disposal. Even empty batteries/rechargeable batteries can contain residual energy that may cause them to swell, burst, catch fire or explode in the event of a short circuit.

10 Technical data

10.1 Power supply

Battery power supply 4.5 V, 3 x 1.5 V, type AA battery

10.2 Light

| Illuminant | LED |
|------------------------|---------------|
| Replaceable illuminant | No |
| LED count | 90 |
| Colour temperature | 3000 - 3200 K |
| | |

10.3 Environment

| Operating temperature | -20 to +40 °C |
|-----------------------|---------------|
| Storage temperature | -20 to +50 °C |

10.4 Others

| Ingress protection | IP44 |
|------------------------------------|---------------------|
| Lead wire length | 1 m |
| Dimensions (W x H x D) (approx.) . | 30 x 42.5 x 30.3 cm |

Weight (approx.) 300 g

This is a publication by Conrad Electronic SE, Klaus-Conrad-Str. 1, D-92240 Hirschau (www.conrad.com).

All rights including translation reserved. Reproduction by any method (e.g. photocopying, microfilming or the capture in electronic data processing systems) requires prior written approval from the editor. Reprinting, also in part, is prohibited. This publication reflects the technical status at the time of printing.

Copyright by Conrad Electronic SE.

*2574832_V1_0922_jh_mh_en 658533131 I1/O1 en