



Download drivers at
evoluent.com/download.htm

Patented. Copyright Evoluent

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Tout changement ou modification non expressément approuvés par la partie responsable de la conformité pourrait annuler l'autorité de l'utilisateur de faire fonctionner l'équipement.

Evoluent VerticalMouse Install

Warning: Wet hand sanitizer may damage the finish on the mouse. Wait for the sanitizer to dry before touching the mouse. Do not use any chemical cleaner on the mouse.

Windows Install

- Before connecting Evoluent VerticalMouse, go to Control Panel, Programs and Features (Win 7) or Add or Remove Programs (XP) to remove any previous Evoluent Mouse Manager and any other existing mouse software, except touchpad driver, to avoid software conflict.
- Before connecting Evoluent VerticalMouse, go to Control Panel, Mouse:
 - In the Buttons tab, uncheck the box for Switch Primary and Secondary Buttons.
 - In the Pointer Options tab, check the box for Enhance Pointer Precision and set the pointer speed slider to the middle position. This is very important.
- Connecting the Evoluent:
 - Wired: Connect the cable to a USB port directly on the computer. The Evoluent may not work with some external USB hubs, docking stations, and KVM switches.
 - Wireless (with receiver): Connect the receiver to a USB port directly on the computer. Slide the On/Off switch to the green position. The Evoluent may not work with some external USB hubs, docking stations, and KVM switches.
 - Bluetooth and Mac models are not compatible with Windows.
- If the Add Hardware Wizard appears, do not select Search for Best Driver, but choose Display All Drivers, and select Human Interface Device (HID) Compliant Mouse.
- Press + or - on the Pointer Speed button on the side of the mouse to light up three indicator lights on the thumb rest for optimal pointer speed.
- The Evoluent logo (wireless with receiver) or a red light on the thumb rest (Bluetooth/Mac) blinks when the battery is low.
- Evoluent Mouse Manager for Windows (driver) may optionally be installed to program the buttons. Download the driver from evoluent.com/download.htm
- During driver install, if a message appears about the driver not passing Windows Testing, click Continue Anyway. This message may appear multiple times. Click Continue Anyway each time.
- After install is finished, button functions may be changed by double clicking the E icon on the task bar to open Evoluent Mouse Manager.

Mac Install

- Before connecting Evoluent VerticalMouse, go to the Applications folder to find and remove any existing Evoluent Mouse Manager and any other mouse software, except touchpad drivers, to avoid software conflict.
- Connecting the Evoluent:
 - Wired: Connect the cable to a USB port directly on the computer. The Evoluent may not work with some external USB hubs, docking stations, and KVM switches.
 - Wireless (with receiver): Connect the receiver to a USB port directly on the computer. Slide the On/Off switch to the green position. The Evoluent may not work with some external USB hubs, docking stations, and KVM switches.
 - Bluetooth/Mac (no receiver): Go to System Preferences, Bluetooth to check the On and Discoverable boxes, and click Setup New Device or the plus sign + to add the mouse. Slide the On/Off switch on the Evoluent to the green position or cycle it off and on to begin pairing.
- Press + or - on the Pointer Speed button on the side of the mouse to light up three indicator lights for optimal pointer speed.
- The Evoluent logo (wireless with receiver) or a red light on the thumb rest (Bluetooth/Mac) blinks when the battery is low.
- Evoluent Mouse Manager for Mac (driver) may optionally be installed to program the buttons. Download the driver at evoluent.com/download.htm
- After install is finished, button functions may be changed by clicking the **E** icon in System Preferences to open Evoluent Mouse Manager.

Suggested grip and posture



Gently hold the VerticalMouse with your fingertips on the side buttons and rest your thumb on the thumb rest. Relax your hand. Press the buttons with a light touch.



A wrist support may be used to reduce pressure points and put the wrist in the proper posture.

Moving the VerticalMouse without moving the pointer



Tilt the VerticalMouse to the side to disable tracking



Slide the VerticalMouse to a new position

Comfort Tips



Sit close to the desk to reduce forward arm extension.

Wrist supports reduce pressure points and put the wrists in neutral postures.

Horizontal arm puts the wrist in a neutral posture. (Lower desk, sit higher, or use keyboard tray.)

Keyboard with number pad on the left makes room for the mouse on the right. (Evoluent Mouse-Friendly Keyboard)

Mouse and keyboard close to the edge of the desk reduce forward arm extension.

Mouse close to the keyboard reduces lateral arm extension.