

User manual

1. Getting the clock started

Insert a battery type LR6 or Type AA according correctly polarized into the battery compartment. The movement will start initializing procedure adjusting the hands to 4'o, 8'o or 12'o'clock position.

2. Signal reception mode:

a. Automated procedure: will start by inserting the battery. After 2 to 10 minutes the hands will adjust to current time, according to transmitter's signal.

b. Manual / Forced enable

Enabled by press the REC button longer than 3 seconds.

The second, minute and hour hand will reset to 12 'o clock position and enter signal reception mode.

The clock sets the hands to the exact time and start working after signal reception successfully. The entire procedure takes 3 - 10 minutes approximately after all hands rest to 12 o'clock.

3. Manual time setup (in areas with no or low signal coverage): press the SET button for more than 3 sec. to start the process. The minute and hour hands will start turning. Keep the button pressed until approaching your required time. For adjusting the second hand keep pressing the SET button in step mode until correct position.

The time will be adjusted automatically when time signal is received later.

4. Reset

Necessary after exchange of battery. Just press the RESET button once after inserting new battery into compartment.

Hints:

Replace the battery after one year, to guarantee the correct function of the clock. After inserting the battery the clock will set the hands to 12'o clock position and starting to receive the radio signal.

Safety instructions

- We do not assume liability for resulting damages to property or personal injury if the product has been abused in any way or damaged by improper use or failure to observe these operating instructions. The guarantee will then expire!
- Unauthorised conversion and/or modification of the device are inadmissible because of safety and approval reasons (CE).
- The appliance must not be subjected to heavy mechanical stress.
- Do not leave packaging materials around unattended; they can become a dangerous toy for children.
- The unit may only be used in dry inside areas.
- Servicing, adjustment or repair works must only be carried out by a specialist/ specialist workshop.

If any questions arise that are not answered in this operating instruction, contact our Technical Advisory Service or other experts.

Dispose of waste electrical and electronic equipment



In order to preserve, protect and improve the quality of environment, protect human health and utilise natural resources prudently and rationally, the user should return unserviceable product to relevant facilities in accordance with statutory regulations. The

crossed-out wheeled bin indicates the product needs to be disposed separately and not as municipal waste.

Used batteries disposal

The user is legally obliged (battery regulation) to return used batteries. Disposing used batteries in the household waste is prohibited! Batteries containing hazardous substances are marked with the crossed-out wheeled bin. The symbol indicates that the product is forbidden to be disposed via the domestic refuse. The chemical symbols for the respective hazardous substances are Cd = Cadmium, Hg = Mercury, Pb = Lead. You can return used batteries free of charge to any collecting point of your local authority, our stores or where batteries are sold. Consequently you comply with your legal obligations and contribute to environmental protection!

Conformity:

Eurotime Uhrenvertriebs GmbH, Schweinfürter Str. 24, 97337 Dettelbach, Germany hereby declares that the item complies with the basic requirements and regulations of Directive 1999/5/EC.

A copy of the signed and dated declaration of conformity can be requested from Info@Eurotime.de

Countries in which R&TTE requirements are met:
All of the EU, Switzerland and Norway

