

BAXTER[®] BACKPACK

Installation and care / Installation et soins

PROPER FITTING INSTRUCTIONS

1. Place sternum loop over the dogs head and rest the pack on the dogs back.
2. Adjust the stabilizer straps (located under each bag) to lower both packs so the lower part of each bag lines up with the center of the dog's side
3. Loop the two side straps under the dog's stomach and clip into the side release buckles.
4. Clip the sternum loop buckle into the clip located on the side strap.
5. Adjust sternum loop and two side straps to fit snugly. This will ensure the load is stable on the dog.
6. Load the two saddlebags with Fido's gear making sure each bag is loaded equally to prevent shifting of the bags. If you find that the pack is slipping to one side readjust the stability straps. (step 2)

INSTRUCTIONS DE MONTAGE APPROPRIÉS

1. Placez la boucle de poitrine sur la tête des chiens et reposez le paquet sur les chiens en arrière.
2. Ajustez les sangles de stabilisation (situées sous eachbag) pour abaisser les deux packs de sorte que la partie inférieure de chaque sac s'aligne avec le centre de la face de chiens.
3. Boucle les deux sangles latérales sous le ventre et le clip du chien dans la libération de côté boucles.
4. Clip de la boucle de la boucle de poitrine dans le clip situé sur la sangle de côté.
5. Réglez boucle de poitrine et deux sangles latérales pour s'adapter parfaitement. Cela permettra d'assurer la charge est stable sur le chien.
6. Chargez les deux sacoches avec la vitesse de Fido en s'assurant que chaque sac est chargé également à empêcher le déplacement des sacs. Si vous trouvez que le bloc glisse d'un côté réajuster les sangles de stabilité. (étape 2)

"ASB" CUSTOM FIT SYSTEM


The Adjustable Saddlebag System allows the Baxter Pack to fit dogs of all sizes.

Smaller dogs:

Storage pouches close together

Larger dogs:

Storage pouches further apart



"ASB" SYSTÈME CUSTOM FIT


Adjustable Saddlebag System permet Pack Baxter pour tenir les chiens de toutes tailles.

Les petits chiens:

Pochettes de rangement rapprochés

Les gros chiens:

Pochettes de rangement plus éloignés



Slide the saddlebags up or down to achieve a fit that is customized for your dog.

Faites glisser les sacoches haut ou le bas pour obtenir un ajustement qui est personnalisé pour votre chien.

Cleaning Instructions

Our product cleaning instructions will help ensure that your gear has a long, exciting life. In general, washing by hand and hang air-drying is the best way to care for your Kurgo products. However, for the occasions when the mess is too great and time is too tight, we recommend using a washing machine.

Hand Wash Instructions

Note: Recommended for small messes.

1. Brush off loose dirt with a dry brush.
2. Spot clean with a damp sponge, cold water, and mild soap. Avoid harsh detergents.
3. If necessary, rinse larger area to eliminate excess soap residue.
4. Hang to air dry (do not machine dry).

Machine Wash Instructions

Note: Only machine wash gentle in front-loading units (DO NOT use machine with an agitator as it could cause damage not covered under the Kurgo Warranty)

1. Secure all buckles and hardware.
2. Wash with cold water and mild soap. Avoid harsh detergents.
3. Rinse thoroughly to eliminate soap residue.
4. Hang to air dry (do not machine dry).



Please contact Kurgo directly with any product or warranty inquiries.