

# Dasqua®

# FIBER GLASS DIGITAL CALIPER


## PRODUCT INSTRUCTION

Please read the product instruction carefully and use the product correctly under the instruction

### FEATURES

- 1、Made of extra strong plastic material , Light weight and durable to use
- 2、Widely range of usage: a teaching tool, familial tool, a tool of carpenter, in the laboratory, in the breeding farm, etc
- 3、Unique switch design, flexible and efficiency

### PICTURE




- 1.MODE BUTTON(Short press metric/inch/fraction conversion)
- 2.ON/OFF BUTTON(Short press to turn on or off)
- 3.ZERO BUTTON

### SPECIFICATIONS AND FUNCTIONS

|                        |                                                  |
|------------------------|--------------------------------------------------|
| Measuring range:       | 76MM-3"/150MM-6"                                 |
| Resolution:            | 0.01MM-0.0005"                                   |
| Accuracy:              | ±0.2MM                                           |
| Measuring system:      | Non-contact linear CAP                           |
| Power:                 | battery,1.5V                                     |
| Operating temperature: | 0°C-+40°C                                        |
| Storage temperature:   | -20°C-+70°C                                      |
| Influence of humidity: | normal operation relative humidity within 0~80%. |

### Battery Replacement

When the display is not clear or not complete on screen, please replace the battery. Unscrew the locking screw on the back of the battery compartment by a screwdriver,remove the battery cover, take out the old batteries, put the new batteries into the compartment with the positive pole up, tighten the locking screw.



### INSTRUCTION

- 1、Keep body faces clean, prevent liquid from getting into the slider for fear of damaging the electronic.
- 2、Faces should be cleaned gently with alcohol or other cleaners. Never use other organic solutions and never clean caliper by immersing it in any liquid.
- 3、Never apply any voltage on any part of the caliper and never use any electric pen in case of amaging its core.
- 4、Other notes refer to conventional calipers.

# Dasqua® GLASFASER DIGITALER MESSSCHIEBER

## PRODUCT INSTRUCTIONS


GB

Please read the product instruction carefully and use the product correctly under the instruction.

### LEISTUNGSMERKMALE

1. Aus extra starkem Kunststoff, leicht und langlebig im Gebrauch.
2. Breites Einsatzspektrum: Lehrinstrument, Werkzeug im Haushalt, Schreinerwerkzeug, im Labor, im Zuchtbetrieb, usw.
3. Einzigartiges Schalterdesign, flexibel und effizient.

### PICTURE




### TECHNISCHE DATEN UND FUNKTIONEN

|                                |                                                         |
|--------------------------------|---------------------------------------------------------|
| Messspanne:                    | 75MM-3"/150MM-6"                                        |
| Auflösung:                     | 0.01MM-0.0005"                                          |
| Genauigkeit:                   | ±0.2MM                                                  |
| Messsystem:                    | Berührungsloser linearer CAP                            |
| Stromversorgung:               | Batterie, 1.5V                                          |
| Betriebstemperatur:            | 0°C-+40°C                                               |
| Lagertemperatur:               | -20°C-+ 70°C                                            |
| Einfluss der Luftfeuchtigkeit: | Normalbetrieb bei relativer Luftfeuchtigkeit von 0~80%. |

### Auswechseln der Batterie

Wenn das Display nicht klar oder nicht vollständig auf dem Bildschirm ist, ersetzen Sie bitte die Batterie. Lösen Sie die Verriegelungsschraube auf der Rückseite des Batteriefachs mit einem Schraubendreher. Entfernen Sie die Batterieabdeckung und nehmen Sie die alten Batterien heraus. Legen Sie die neuen Batterien mit dem Pluspol nach oben in das Batteriefach und ziehen Sie die Verriegelungsschraube fest.



Verriegelungsschraube

### ANLEITUNG

1. Halten Sie die Gehäuseoberflächen sauber und verhindern Sie, dass Flüssigkeit in den Schieber eindringt, damit die Elektronik nicht beschädigt wird.
2. Die Flächen sollten vorsichtig mit Alkohol oder anderen Reinigungsmitteln gereinigt werden. Verwenden Sie keine anderen organischen Lösungen und tauchen Sie den Messschieber niemals in eine Flüssigkeit.
3. Legen Sie niemals Spannung an irgendeinem Teil des Messschiebers an und verwenden Sie niemals einen Elektrostift, damit dessen Kern nicht beschädigt wird.
4. Weitere Hinweise finden sich bei herkömmlichen Messschiebern.