







Model Number

UB300-18GM40-E5-V1


Single head system

Features

- Short design, 40 mm
- Function indicators visible from all directions
- · Switch output
- 5 different output functions can be set
- Program input
- · Temperature compensation

Curves

Characteristic response curve



Curve 1: flat surface 100 mm x 100 mm Curve 2: flat surface 10 mm x 10 mm Curve 3: round bar, Ø 25 mm



Technical data

General specifications

Sensing range 30 ... 300 mm

Adjustment range 50 ... 300 mm

Unusable area 0 ... 30 mm

Standard target plate 100 mm x 100 mm

Transducer frequency approx. 390 kHz

Response delay approx. 30 ms

Indicators/operating means

LED green Power on LED yellow indication of the switching state

flashing: program function object detected

LED red solid red: Error red, flashing: program function, object not detected

Electrical specifications

Operating voltage U_B 10 ... 30 V DC , ripple 10 $\%_{SS}$

No-load supply current $I_0 \le 20 \text{ mA}$

Input Input type 1 program input

operating distance 1: -U_B ... +1 V, operating distance 2: +6 V

... +U_B

input impedance: > 4,7 k Ω program pulse: \geq 1 s

Output type 1 switch output E5, PNP NO/NC, programmable

Rated operational current I_e 200 mA , short-circuit/overload protected

Default setting Switch point A1: 50 mm Switch point A2: 300 mm

 $\begin{array}{lll} \mbox{Voltage drop U}_d & \leq 3 \ \mbox{V} \\ \mbox{Repeat accuracy} & \leq 1 \ \% \\ \mbox{Switching frequency f} & \leq 13 \ \mbox{Hz} \\ \end{array}$

Range hysteresis H 1 % of the set operating distance

Temperature influence \pm 1.5 % of full-scale value

Ambient conditions

Ambient temperature $-25 \dots 70 \,^{\circ}\text{C} \, (-13 \dots 158 \,^{\circ}\text{F})$ Storage temperature $-40 \dots 85 \,^{\circ}\text{C} \, (-40 \dots 185 \,^{\circ}\text{F})$

Mechanical specifications

Connection type Device connector M12 x 1 , 4-pin

Protection degree IP67

Material

Housing brass, nickel-plated
Transducer epoxy resin/hollow glass sphere mixture; foam

polyurethane, cover PBT

Mass 25 g

Compliance with standards and directives

Standard conformity

Standards EN 60947-5-2:2007


IEC 60947-5-2:2007

Approvals and certificates

Pepperl+Fuchs Group • Tel.: Germany +49 621 776-0 • USA +1 330 4253555 • Singapore +65 67799091 • Internet http://www.pepperl-fuchs.com


UL approval cULus Listed, General Purpose
CSA approval cCSAus Listed, General Purpose

Dimensions



Electrical Connection

Standard symbol/Connections: (version E5, pnp)



Core colours in accordance with EN 60947-5-2

Pinout

Connector V1



Adjusting the switching points

The ultrasonic sensor features a switch output with two teachable switching points. These are set by applying the supply voltage -U $_{\rm B}$ or +U $_{\rm B}$ to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. Switching point A1 is taught with -U $_{\rm B}$, A2 with +U $_{\rm B}$.

Five different output functions can be set

- 1. Window mode, normally-open function
- 2. Window mode, normally-closed function
- 3. one switching point, normally-open function
- 4. one switching point, normally-closed function
- 5. Detection of object presence

TEACH-IN window mode, normally-open function


- Set target to near switching point
- TEACH-IN switching point A1 with -U_B
- Set target to far switching point
- TEACH-IN switching point A2 with +U_B

TEACH-IN window mode, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A2 with +U_B

Additional Information

Programmable output modes



5. A1 -> ∞, A2 -> ∞: Object presence detection mode Object detected: Switch output closed No object detected: Switch output open

Accessories

UB-PROG2

Programming unit

OMH-04

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

RF 18

Mounting flange, 18 mm

RF 18-F

Mounting flange with dead stop, 18 mm

BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

V1-G-2M-PVC

Cable socket, M12, 4-pin, PVC cable

V1-W-2M-PUR

Cable socket, M12, 4-pin, PUR cable

- · Set target to far switching point
- TEACH-IN switching point A1 with -U_B

TEACH-IN switching point, normally-open function

- Set target to near switching point
- TEACH-IN switching point A2 with +U_B
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -U_B

TEACH-IN switching point, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A1 with -U_B
- · Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A2 with +U_B

TEACH-IN detection of objects presence

- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -U_B
- TEACH-IN switching point A2 with +U_B

Default setting of switching points

A1 = blind range, A2 = nominal distance

LED Displays

Displays in dependence on operating mode	Red LED	Yellow LED
TEACH-IN switching point:		
Object detected	off	flashes
No object detected	flashes	off
Object uncertain (TEACH-IN invalid)	On	off
Normal operation	off	Switching state
Fault	on	Previous state

Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF18, BF18-F or BF 5-30 must be used.

In case of direct mounting of the sensor in a through hole using the steel nuts, it has to be fixed at the middle of the housing thread. If a fixation at the front end of the threaded housing is required, plastic nuts with centering ring (accessories) must be used.