INSTRUCTION SHEET

Photoelectric Switch with Built-in Power Supply SA1U Series

Universal Voltage · DC Power Types/With or Without Time-delay Outputs


Detection Mode	Universal Voltage Type	DC Power Type	
Through-beam	SA1U-T50M (T)	SA1U-T50MW (T)	
Polarized Retro-reflective	SA1U-P07M (T)	SA1U-P07MW (T)	
Diffuse-reflective	SA1U-D01M (T)	SA1U-D01MW (T)	
Background Suppression	SA1U-B02M (T)	SA1U-B02MW (T)	

Confilm that the delivered product is what you have ordered. Read this instruction sheet to make sure of correct operation. Make sure that the instruction sheet is kept by the end user.


SAFETY PRECAUTIONS


/ CAUTION


Caution notices are used where inattention might cause personal injury or damage to



2 Dimensions (mm)







Tighten all screws surely to maintain the water-proof characteristics. (Except for UL / c-UL)

Excessive tightening causes damage. Tighten the screws within the tightening torque range shown at Screw Tightening Torque 0.6 to 1.0 Terminal 4.0 to 6.0 Gland Cover Screw 0.5 to 0.8 0.8 to 1.2 Mounting Screw

4 Specifications

Sensing Method				Through-beam	Polarizedb Retro-reflective Diffuse-reflective Background Suppression		Background Suppression	
Type No.	Universal		Without Time-delay	SA1U-T50M	SA1U-P07M SA1U-D01M		SA1U-B02M	
	Voltag	tage	With Time-delay	SA1U-T50MT	SA1U-P07MT	SA1U-D01MT	SA1U-B02MT	
	DC	:	Without Time-delay	SA1U-T50MW	SA1U-P07MW	SA1U-D01MW	SA1U-B02MW	
	Pov	wer	With Time-delay	SA1U-T50MWT	SA1U-P07MWT	SA1U-D01MWT	SA1U-B02MWT	
Specifications	Sensing Range		inge	50m	0.2 to 7m (Using the attached reflector)	1m (200 x 200mm white mat paper)	0.2 to 2m (200 × 200mm white mat paper)	
	Detectable Object		Object	Opaque	Opaque/Specular	Opaque/Specular	Opaque	
	Hysteresis			-	1	20% maximum of operation distance	15% maximum of operation distance	
	Light Source Eiement		e Eiement	Infrared LED	Infrared LED	Infrared LED		
	Extraneous Light immunity		Light immunity	Sunlight 10000lx maximum, Incandescent lamp 5000lx maximum				
	Temperature Range		e Range	-25 to 60 (no freezing), Storage temperature: -40 to 70 (no freezing)				
	Operating Humidity		Humidity	35 to 85% RH (storage temperature)				
	Degree of Protection		Protection	IP67 (IEC/EN60529) NEMA TYPE 1 (For UL / c-UL)				
Universal Voltage Type	Power Voltage		age	24 to 240V AC (21.6 to 264V AC) 50/60Hz, 12 to 240V DC (10.8 to 264V DC)				
	Power Consumption		sumption	Projector: 3 VA maximum	3 VA maximum			
			Sumption	Receiver: 3 VA maximum	VA IIIAAIIIUIII			
	Output			Electromechanical SPDT, Swithing capacity: 250V AC • 3A (resistive load), 30V DC • 3A (resistive load)				
'n	Response Time		Гіте	20ms maximum				
	Power Voltage		age	12 to 24V DC, Ripple p-p 10% maximum (10 to 30V DC)				
DC Power Type	Power Consumption		sumption	Projector: 20 mA maximum	aximum 30 mA maximum			
			Sumption	Reciever: 25 mA maximum	ciever: 25 mA maximum			
	l l	Config	uration	NPN and PNP transistor ope	tor open collector			
	Output	Resisti	ve Load	100 mA maximum				
	Output Voltage		Voltage	30V DC maximum				
"	Voltage Drop		e Drop	2.4V maximum				

5 Notes for Operation

Response Time

- · Prevent incidence of reflected light from the floor or wall.
- · Do not expose the photoelectric switch to sunlight or other direct light projections
- · Do not strike the photoelectric switch with a hammer when instlalling, otherwise the waterproof characteristics will be impaired. (Except for UL / c-UL)

1 ms maximum

- · For preventing the transient state when turning power on, a circuit to turn output off (universal voltage: 200 ms, DC power: 50 ms) is contained. On the timer-function model, time-delay operation starts when the output is released from the off state. Take care of the operation when turning power on.
- · Do not use the photoelectric switch under conditions exceeding the rated operating temperature, vibration resistance, and shock resistance.
- Use the photoelectric switch within the rated power voltage
- · When using a switching power supply, connect the FG (frame ground) terminal to a proper ground.
- · When compliance with the EU Low Voltage Directive is required, connect an EN approved fuse outside the power terminals of the universal voltage type.
- Install the cover maintain the water-proof characteristics, install the cover in a regulated position.


CAUTION

Type No, and the wiring diagram, are indicated on the housing and the cover. When installing the cover, confirm that the cover type the agrees with the housing

6 Wiring Diagram


Universal Voltage Type

Other than the through-beam type projector




type projector


DC Power Type



Through-beam type projector


Through-beam type projector






Internal Circuit →·····○ → External Wiring

Cable Connection






Connect wires starting from the lower terminals


Install the cover using the captire screw.

Use a cable of 8 to 10 mm in diameter to ensure water- and dust-proof characteristics(Except for UL / c-UL). Two gland packings are supplied; for cables of 8 to 9 mm and 9 to 10 mm in diameter. Use a proper gland packing and a gland washer, and tighten the gland firmly. Keep the cable insulation within 5 mm from the gland packing as shown above. Make sure that the gland washer is placed in the gland packing correctly.

- Turn off the power supply before wiring.
- ·Connect correctly to prevent damage
- ·The power voltage must not exceed the rated range
- •The cable should not be run in the same wire duct with other power supply, motor, or electromagnetic lines because induction noise will cause malfunction or damage to the
- ·Cable extension is allowed up to 100m using a cabtyre cable with core wires of 0.3 mm² or more. On the DC power supply type, consider the voltage drop by the resistance of the cable.
- · When connecting crimping terminals, note the direction of the crimping part as shown.



Applicable Crimping Terminal Dimensions



- ·When using crimping terminals, wrap the terminal with insulating tubes
- ·Each screw terminal can accept only one crimping terminal.

7 Optical Axis Alignment & Sensitivity Adjustment

(1) Through Beam Type

Direct the projector and the receiver face by eye measure and fasten them tentatively. Direct the receiver upward, downward, and sideways and lock the projector in the middle where the indicator on the receiver goes on.

(2) Polarized retro-reflective

Direct the sensor upward, downward, and sideways and lock the reflector in the middle where the indicator goes on or off.

(3) Diffuse-reflective

Place the sensing object and direct the sensor upward, downward, and sideways and lock the reflector in the middle where the indicator goes on or off. Without the sensing objects in place, check the indicator goes off. If the background influences, make the sensitivity adjustment as follows.

- (a) With the sensing object in place, turn the sencitivity adjusting control clock wise from MIN position until the indicator goes on (point A).
- (b) Remove the object, then the indicator will go off. Turn the sensitivity adjusting control further clockwise until the indicator goes on again by detecting the background (Point B).
- (c) Set the sensitivity adjusting control at Point C, the middle point between A and B. This point gives the best sensitivity. NOTE: Use the attached screwdriver to make adjustments. Avoid excessive force to the

sensitivity adjusting control to prevent damage. (4) Make the sensitivity adjustment of the background suppression (BGS) as follows

(At dark on operation, read lighting the operation indicator in a different way as turning off and adjust it.)


First, direct the sensor and place the object, turn the sensitivity adjusting control counterclockwise until the indicator goes off. Then turn the sensitivity adjusting control clockwise until the indicator goes on (Point A).

Remove the object, then the indicator will go off. Turn the sensitivity asjusting control further clockwise until the indicator goes on again by detecting the background (Point B) (*1). Set the sensitivity adjusting control at Point C, the middle point between A and B (*2).

*1: Make one turn or more clockwise from point A and set the position as point C when the background is too far and the operation LED dose turn on.

*2: There may be more than 1 turn between points points A and B, since this photelectric switch incorporates a 6-turn adjuster.

8 Operation Chart



IDEC CORPORATION

http://www.idec.com