# Accutire® Key Chain

### Electronic Digital Pressure Gauge Extends the life of your tires

Specifications

Range: 5-60 PSI or 0.5-7 Bar or 50-700 KPA

Accuracy: ±1%+LSD

Operating Temperature: 0-100°F (-18° to 33°C) Power: Permanent Lithium Coin Cell

#### Instructions

- Push nozzle of Accutire® on to tire valve.
   Make sure a good seal is made between the
   nozzle and the valve stem so that no hissing
   sound of escaping air is heard.
- Hold gauge on valve stem until reading locks on the display.
- Promptly remove gauge from valve stem and read pressure.
   You may continue to use the gauge even though the previous reading is still displayed by following the instructions above.

Note: The gauge will shut off automatically.

#### Zero Set

The gauge is a precision electronic instrument and from time to time it is advisable to check the zero setting, especially at extreme hot and cold temperatures. To check the zero setting: Briefly press the gauge on to the tire valve. It is not necessary for a good seal to be made. Only a small amount of air must enter the gauge to zero set the unit. When the display starts to flicker, promptly remove gauge from valve stem. Your Accutire has been recalibrated.

#### What To Do If

- You do not get any reading at all (either blank display or all zeros): See the instructions and follow them carefully. If gauge still does not work, see Warranty & Service section.
- see Warranty & Service section.

   You observe "L" on the display:
  The power supply has been depleted.
  See Warranty & Service section.
- You observe an unusually high/low reading: Make sure no sound of escaping air is heard in step #1 of instruction. Also, make sure you are checking the pressure on cool tires which have not been driven on for several hours.

Helpful Hints

- Always be sure to follow tire manufacturer's recommended pressure ratings which are based on "cool" tire temperatures.
- The electronic module and power cell are factory sealed in the unit. There are no user serviceable parts.
- To clean the gauge, use a soft damp cloth. Do not immerse in, or spray with water or other liquid cleaner.

Warranty & Service

Measurement Ltd. (MSL) warrants this gauge against defects in material or workmanship for a period of 1 years from the date of purchase and agrees to repair or replace it free of charge (Note: the Lithium coin cell carries a 10 year warranty). This warranty does not cover damage resulting from misuse or abuse of the product.

## OPENING OR TAKING APART THE GAUGE WILL VOID WARRANTY.

Should your gauge require service, we suggest you first return it to the place of purchase. If the store does not replace the gauge, you may send it back to MSL for repair or replacement. Our authorized service center address is:

Measurement Limited Flat A-B, 12/F., Block A, Wo Kee Hong Bulding, 585-609 Castle Peak Road, Kwai Chung, N. T. HK

Please take care in packing the gauge so it will not be damaged while in transit. MSL is not responsible for freight costs to our service center. You should send the package freight prepaid. We also recommend that the package be insured in case of damage or theft while in transit.

US Pat. No's 4,250,759;4,704,901; and 4,748.845



Made in China