

metabo®

ULA 14.4-18



ENG Original instructions..... 4

Original instructions

1 General Safety Instructions



WARNING – Reading the operating instructions will reduce the risk of injury.



WARNING Read all safety warnings and instructions. Failure to follow all safety warnings and instructions may result in electric shock, fire and/or serious injury.

Keep all safety instructions and information for future reference.

Always charge batteries in chargers recommended by the manufacturer. Chargers designed for a specific type of battery may pose a fire hazard when used together with other battery types.

Always insert the correct batteries in the battery hand lamp. Using other batteries may cause injuries and pose a fire hazard.

When not in use, keep batteries away from paper clips, coins, keys, nails, screws or other small metal objects that could bridge the contacts. Short circuits between battery contacts can cause burns or fires.

Fluid may escape if batteries are used inappropriately. Avoid all contact with this fluid. In the event of accidental skin contact, rinse the affected area thoroughly. If the fluid enters your eyes, seek immediate medical assistance. Escaping battery fluid can cause skin irritation or burns.

Do not operate the battery hand lamp in potentially explosive environments where flammable dust, fluids or gases are located. The lamp can generate sparks which may ignite dust or vapours.

Avoid accidental operation. Make sure that the battery hand lamp is switched off before connecting the battery and picking up or carrying the lamp. Accidentally pressing the switch on the device or connecting the device to the power supply when already switched on can lead to accidents.

Always switch off the battery hand lamp when not in use.

Never use electrical devices with a defective switch. Electrical devices that can no longer be switched on or off are dangerous and must be repaired immediately.

Remove the battery before adjusting, cleaning and storing the device or changing accessories. These precautionary measures prevent accidental operation of the battery hand lamp.

When not in use, keep the battery hand lamp out of the reach of children. Do not allow personnel to use the device unless they are already familiar

with it or have read these instructions. Electrical devices are dangerous when used by inexperienced personnel.

Maintain the device carefully. Check that all moving parts are functioning correctly and do not seize, make sure that no parts are broken or damaged to an extent where they affect the function of the battery hand lamp. Have damaged parts repaired before using the device. Many accidents are caused by poorly maintained electrical tools.

Use the battery hand lamp, accessories, etc. as described in these instructions. Take into consideration the working conditions and tasks required. Using electrical devices for applications other than those intended can lead to dangerous situations.

Always have your battery hand lamp repaired by qualified personnel using genuine spare parts. This will ensure that the device functions safely.

Keep your battery hand lamp away from heat sources and fires. Do not store your battery hand lamp in moist or wet ambient conditions. Do not store in locations where temperatures may reach or exceed 40 °C. Examples include alcoves, motor vehicles or metal structures during the summer.

Do not clean with aggressive cleaning agents.

Do not leave the battery hand lamp switched on unattended.

Protect battery packs from water and moisture!

Do not expose battery packs to naked flame!

Do not use faulty or deformed battery packs!
Do not open battery packs!
Do not touch or short-circuit battery packs!

Slightly acidic, flammable fluid may leak from defective Li-ion battery packs!

If battery fluid leaks out and comes into contact with your skin, rinse immediately with plenty of water. If battery fluid leaks out and comes into contact with your eyes, wash them with clean water and seek medical attention immediately.

Warning - general danger!

Battery packs must not be disposed of with regular waste. Return faulty or used battery packs to your Metabo dealer!

Do not allow battery packs to come into contact with water!

2 Overview

See image on the title page.

- 1 Battery pack
- 2 Battery pack release button
- 3 Switch (on/off)
- 4 Window
- 5 Locking ring
- 6 Adjusting ring
- 7 Lamp head

3 Use

Insert a fully charged battery pack (1) (not included in the scope of delivery). Turn on and off at the switch (3). Tilt the lamp head (7) to adjust the angle of the light beam. Adjust the light beam by turning the adjusting ring (6). Do not direct the light beam into the eyes of people or animals.



Caution! The window (4) may become very hot. Risk of burning! Do not touch!

4 Maintenance / Changing the bulb

Caution! Window (4), light bulb and reflector can become very hot. Risk of burning! Allow to cool before dismantling.

Press the battery pack release (2) button and remove the battery pack (1). Hold the adjusting ring (6) and unscrew the locking ring (5). Remove the reflector. Turn the bulb until the notch on the metal collar lines up with the retaining lobe on the bulb socket. Remove the bulb from the socket. Insert new bulb (in order to not shorten the service life of the bulb, do not touch the bulb with your bare hands.) Reassemble.

5 Repairs



Repairs to Metabo machines must be carried out by qualified electricians only!

Metabo machines requiring repairs can be sent to the address specified on the spare-parts list. Please enclose a description of the fault with the device.

6 Environmental Protection

Battery packs must not be disposed of with regular waste. Return faulty or used battery packs to your Metabo dealer!

Do not allow battery packs to come into contact with water!



Only for EU countries: Never dispose of power tools in your household waste! In accordance with European Guideline 2002/96/EC on used electronic and electric equipment and its implementation in national legal systems, used power tools must be collected separately and handed in for environmentally compatible recycling.

7 Technical Specifications

Voltage range: 14.4 - 18 V

Bulb order no.:



343 074 560
(5.2 V, 0.85 A, base P13.5s)

For use with Metabo battery packs: 6.25468, 6.25469, 6.25457, 6.25459, 6.25467, 6.25456, 6.25458.

Metabowerke GmbH
Postfach 1229, 72602 Nürtingen, Germany
www.metabo.com

Changes due to technological progress reserved.
© by Metabo

metabo[®]

Metabowerke GmbH,
72622 Nürtingen, Germany
www.metabo.com