

AC DIGITAL CLAMP METER KEW 2007R/2117R/2127R




KEW 2007R/2117R/2127R Specifications

	KEW 2007R	KEW 2117R	KEW 2127R		
AC A	600.0/1000A (Auto-ranging) ±1.5%rdg±4dgt [45 - 65Hz] ±2.0%rdg±4dgt [40 - 400Hz]	60.00/600.0/1000A (Auto-ranging) ±1.5%rdg±4dgt [45 - 65Hz] ±2.0%rdg±5dgt [40 - 1kHz]			
AC V	600.0V ±1.2%rdg±3dgt [45 - 65Hz] ±1.5%rdg±4dgt [40 - 400Hz]	60.00/600.0V (Auto-ranging) ±1.0%rdg±2dgt [45 - 65Hz] (600V) ±1.5%rdg±4dgt [40 - 1kHz] (60/600V)			
DC V	600.0V ±1.2%rdg±3dgt	60.00/600.0V (Auto-ranging) ±1.0%rdg±3dgt (60V), ±1.2%rdg±3dgt (600V)			
Ω	$ \begin{array}{l} 600.0\Omega/6.000k\Omega \; (\mbox{Auto-ranging}) \\ \pm 1.3\%\mbox{rdg} \pm 5\mbox{dgt} \; (\mbox{600}\Omega) \\ \pm 2.0\%\mbox{rdg} \pm 3\mbox{dgt} \; (\mbox{6k}\Omega) \end{array} $	$ \begin{array}{l} 600.0\Omega/6.000/60.00/600.0k\Omega \; \text{(Auto-ranging)} \\ \pm 1.0\%\text{rdg} \pm 5\text{dgt} \; \text{(}600\Omega\text{)} \\ \pm 2.0\%\text{rdg} \pm 3\text{dgt} \; \text{(}6/60/600k\Omega\text{)} \end{array} $	$ \begin{array}{l} 600.0\Omega/6.000/60.00/600.0k\Omega/6.000/40.00M\Omega(\mbox{Auto-ranging}) \\ \pm 1.0\%rdg\pm 5dgt(600\Omega), \pm 2.0\%rdg\pm 3dgt(6/60/600k\Omega) \\ \pm 3.0\%rdg\pm 3dgt(6M\Omega), \pm 5.0\%rdg\pm 3dgt(40M\Omega) \end{array} $		
Continuity buzzer	600Ω (Buzzer sounds below $90Ω$)				
Hz	_	_	999.9Hz/9.999kHz (Auto-ranging) ±0.1%rdg±3dgt (Input sensitivity Current:more than 4A Voltage:more than 2V)		
Capacitance test	_	_	1.000/10.00/100.0 µF ±3.0%rdg±15dgt (1 µF) ±3.0%rdg±10dgt (10/100 µF)		
Diode test	_	_	2.000V ±4%rdg±5dgt Open-loop Voltage:<3.5V		
Conductor size	Ø33mm max.				
Applicable Standards	IEC 61010-1 CAT № 300V, CAT Ⅲ 600V Pollution degree 2 IEC 61010-031, IEC 61010-2-032, IEC 61010-2-033, IEC 61326-2-2(EMC), IEC 60529 IP40, EN 50581(RoHS)				
Power source	R03/LR03(AAA)(1.5V)x2				
Continuous measuring time	Approx. 170 hours (when R03 is used) (Auto power save : approx. 10 minutes) (NCV_LED**, Backlight*2.off)				
Dimensions	$204(L) \times 81(W) \times 36(D)mm$				
Weight	220g approx. (including batteries) 230g approx. (including batteries)				
Accessories	7066A (Test leads), 9079 (Carrying case), R03 (AAA)×2, Instruction manual				

^{*12117}R, 2127R *2127R only

Included Accessories








*2127R only

Selection Guide

Selection G	NEW		
	2007R	2117R	2127R
Continuity buzzer	0	0	0
NCV	×	0	0
Capacitance test	×	×	0
Diode test	×	×	0
Back light	×	×	0
Peak hold	×	×	0

Peak hold Function (2127R only) Press the SELECT key on ACA, ACV or DCV function to start PEAK measurement. The LCD shows updates the max measured value repeatedly during a measurement.



True RMS function for accurate readings also in presence of modern loads such as LED lamps, motor inverters, PCs, TVs, Air conditioners, etc.						
Waveform	True RMS type	Averaging value type				
	√ correct reading	√ correct reading				
	√ correct reading	higher reading				
	√ correct reading	lower reading				
	√correct reading	lower reading				



Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely for correct use. Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

Cosinus Messtechnik GmbH Rotwandweg 4 D-82024 Taufkirchen Tel 089-665594-0 Fax 089-665594-30

e-Mail: office@cosinus.de Internet: www.cosinus.de