Distance sensor



CE 🚷 IO-Link

Model Number

OMT300-R201-IEP-IO-V1

Distance sensor with 4-pin, M12 x 1 connector

Features

- Medium design with versatile • mounting options
- Space-saving distance sensors in ٠ small standardized design
- Multi Pixel Technology (MPT) exact • and precise signal evaluation
- IO-link interface for service and process data
- Analog output 4 ... 20 mA

Product information


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and can be adapted to the application


environment.



Electrical connection









Wire colors in accordance with EN 60947-5-2 ΒN (brown) (white) WH BU BK (blue) (black)

3 4

Indicators/operating means





1	Mode rotary switch	
2	Teach-in button	
3	Switching output display Q1	YE
4	Operating indicator	GN

Q1B	Switching output/switch point B
Q1A	Switching output/switch point A
Q2A	Analog output/value A
Q2B	Analog output/value B
0	Keylock

eng.xml

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Technical data			Accessories
General specifications			
Measurement range		100 300 mm	V1-G-2M-PUR
Reference target		standard white, 100 mm x 100 mm	Female cordset, M12, 4-pin, PUR cable
Light source		LED	V1-W-2M-PUR
Light type		modulated visible red light	Female cordset, M12, 4-pin, PUR cable
LED risk group labelling		exempt group	
Angle deviation		max. +/- 1.5 °	IO-Link-Master02-USB
Diameter of the light spot		approx. 8 mm at a distance of 300 mm	IO-Link master, supply via USB port or
Angle of divergence		1.8 °	separate power supply, LED indicators,
Ambient light limit		EN 60947-5-2 : 45000 Lux	M12 plug for sensor connection
Resolution		0.1 mm	
Functional safety related pa	rameters		Other suitable accessories can be found at
MTTF _d		520 a	www.pepperl-fuchs.com
Mission Time (T _M)		20 a	
Diagnostic Coverage (DC)		0 %	
Indicators/operating means			
Operation indicator		LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode	
Function indicator		LED yellow: constantly on - switch output active constantly off - switch output inactive	
Control elements		Teach-In key	
Control elements		5-step rotary switch for operating modes selection	
Electrical specifications			
Operating voltage	U _B	18 30 V DC	
Ripple		max. 10 %	
No-load supply current	I ₀	< 25 mA at 24 V supply voltage	
Protection class		111	
Interface			
Interface type		IO-Link (via C/Q = pin 4)	
Device profile		Identification and diagnosis Smart Sensor type 0/type 3.3	
Transfer rate		COM 2 (38.4 kBaud)	
IO-Link Revision		1.1	
Min. cycle time		3 ms	
Process data witdh		Process data input 4 byte	
		Process data output 2 bits	
SIO mode support		yes	
Device ID		0x111915 (1120533)	
Compatible master port type		A	
Output			
Switching type		The default setting is: C/Q - Pin4: NPN normally open, PNP normally closed, IO-Link I—Pin2: analog output 420 mA	
Signal output		1 push-pull output , 1 analog output , short-circuit-proof, reverse polarity protection, surge-proof	
Switching voltage		max. 30 V DC	
Switching current		max. 100 mA , resistive load	
Usage category		DC-12 and DC-13	
Voltage drop	U _d	≤ 1.5 V DC	
Response time		2 ms, see table 1	The second se
Analog output		1 current output: 4 20 mA	
Output type Load resistor		> 1 k Ω voltage output; \leq 470 Ω current output	
Recovery time		2 ms	000277
-		2 1115	
Conformity Communication interface		IEC 61131-9	
Product standard		EN 60947-5-2	
Measurement accuracy			
Temperature drift		0.05 %/K	
Warm up time		5 min	FOC STATES
Repeat accuracy		< 0.5 % , see table 1	
Linearity error		0.5 %	
Ambient conditions			
Ambient temperature		10 50 °C (50 122 °F)	È
Storage temperature		-40 70 °C (-40 158 °F)	Ş
Mechanical specifications			
Housing width		15 mm	
Housing height		61.7 mm	
Housing depth		41.7 mm	Ċ
Degree of protection		IP67 / IP69 / IP69K	
Connection		4-pin, M12 x 1 connector, 90° rotatable	
Material		, , ,	

Refer to "General Notes F
Pepperl+Fuchs Group
www.pepperl-fuchs.com

2

> "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

fa-info@de.pepperl-fuchs.com

Germany: +49 621 776 4411

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Housing		PC (P	olycarbonate)		
Optical face		PMMA	4			
Mass		appro	x. 47 g			
Approvals and certif	icates					
UL approval		E870	56 , cULus L	isted , class 2	power supp	ly , type ra
CCC approval		CCC	approval / m	arking not rec	uired for pro	ducts rate
Table 1: Inform	ation on I	Measure	d Value	Filters		
Measured value	filter					
Filter	1-way	2-way	4-way	16-way	64-way	256-w

Fliter	1-way	2-way	4-way	16-way	64-way	256-way
Response time (ms)	2	4	8	32	128	512
Repeatability (%)		< 0.5 %				

Settings

Teach-In (TI)

Use the rotary switch for switching signal Q1 to select the relevant switching threshold A and/or B to teach in.

• The yellow LEDs indicate the current state of the selected output.


To teach in a switching threshold, press and hold the "TI" button for approximately 1 s, until the yellow and green LEDs flash in phase. Teach-in starts when the "TI" button is released.

rating 1 ed ≤36 V


- Teach-in successful: the yellow and green LEDs flash alternately at 2.5 Hz.
- Teach-in unsuccessful: the yellow and green LEDs quickly flash alternately at 8 Hz.

After an unsuccessful Teach-in, the sensor continues to operate with the previous valid setting after the relevant visual fault signal is issued. Set switching mode: you can define different switching modes by teaching in the relevant distance data for switching thresholds A and B.

1. Single point mode:



2. Window mode:



Teach in switching thresholds: you can teach in or overwrite a taught-in switching threshold at any time. To do this, press the "TI" button again.

Reset a value: you can reset a taught-in value. To do this, press the "TI" button for > 4 s, until the yellow and green LEDs go out. The reset process itself starts when the "TI" button is released.

Reset successful: the yellow and green LEDs flash alternately at 2.5 Hz.

Minimum and maximum values for the analog output Q2 are taught in and deleted in the same way as those for the switching output.

The following applies:

A = Minimum voltage/current

B = Maximum voltage/current

Resetting to Factory Settings

To revert back to factory settings, press the "TI" button for > 10 s with the rotary switch set to position "O," until the yellow and green LEDs go out at the same time. The reset process itself starts when the "TI" button is released.

• Reset to factory settings successful: the yellow and green LEDs light up at the same time. The sensor then continues to operate with factory settings.

OMT-IEP

- Factory setting for switching signal Q1:
- Switching signal is high active, window mode
- Analog output: current output, 4 mA ... 20 mA absolute mode
- OMT-UEP
- Factory setting for switching signal Q1:
- Switching signal is high active, window mode
- Analog output: voltage output, 0 V ... 10 V absolute mode

Analog output

www.pepperl-fuchs.com

The analog output type can be configured as voltage or current output via IO-Link.

- The following output types are available:
- Analog output 0 mA ...20 mA

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



- Analog output 4 mA ...20 mA
- Analog output 0 V ...10 V

The following operating modes are available:


- Absolute mode (default setting)
- Normalized mode
- Rising slope
- Falling slope

The following substitute values can optionally be configured:


- No substitute values used (default setting)
- Substitute value for "no measured value" used
- Substitute value for "no measured value" and "Measuring overrange" used

The sensor's tolerances are based on the digital process data.


Absolute mode (default setting, A and B = deleted)



Normal mode (A and B without teach-in / deleted)




Rising slope (A < B)





4

Falling slope (A > B)



Configuration via IO-Link interface

Setting different operating modes via the IO-Link interface

The devices are equipped with an IO-Link interface as standard for diagnostics and parameterization tasks to ensure optimum adjustment of the sensors to the relevant application.

Single point mode operating mode (one switch point):

- "Detection of objects irrespective of type and color in a defined detection range. Objects in the background are suppressed.
- "The switch point corresponds exactly to the set point.

acti	ive detection range
	Background
	suppression

Window mode operating mode (two switch points):

- Detection of objects irrespective of type and color in a defined detection range. Reliable detection when object leaves the detection range.
- Window mode with two switch points.

d	ictive detection range	
Foreground suppression	Backgro	und suppression

active detection range

Center window mode operating mode (one switch point):

- Detection of objects irrespective of type and color in a defined detection range. Sets a defined window around a given object. Objects outside this window are not detected.
- · Window mode with one switch point.

active	detection range
Foreground suppression	Background suppression

Two point mode operating mode (hysteresis operating mode):

fa-info@us.pepperl-fuchs.com

• Detection of objects irrespective of type and color between a defined switch-on and switch-off point.

	a	ictive detection range		
Output	V	Hysteresis	Outpu	t
Inactive operating moEvaluation of switch	ode: ning signals is deactivated	d.		
The associated IODE	D device description file	e can be found in the dowr	load area at www.pep	perl-fuchs.com
Refer to "General Notes Relatin Pepperl+Fuchs Group	g to Pepperl+Fuchs Product Infor USA: +1 330 486 0001	mation". Germany: +49 621 776 4411	Singapore: +65 6779 9091	PEPPER

fa-info@de.pepperl-fuchs.com

fa-info@sg.pepperl-fuchs.com



www.pepperl-fuchs.com