(2) Mode: Long press mode switch hole for 3 seconds to switch the temperature measurement mode (Sur: surface mode, bod: object mode, Cou: counting mode)









Fig. 13

Fig. 11

1.Surface mode: measuring the surface temperature of an object (any object).

- 2.Object Mode: measurement range is between 35 $\,^{\circ}$ $\,^{\circ}$ 42 $\,^{\circ}$ with alarm. 3.Counting mode: each measurement is incremented in order according to the law of natural numbers.
- 3.Install and replace battery
- (1) Remove three screws
- (2) Open the back base and install 18650 Li battery




5.Warnings

- It is the user's responsibility to ensure the electromagnetic compatibility environment of the device so that the device can work normally.
- 2.It is recommended to evaluate the electromagnetic environment before using the device.
- $3. When changing the operating environment, the device must be left to stand for more than <math display="inline">\ensuremath{\mathsf{S}}$ 30 minutes.
- 4.It is not recommended to use it outdoors or under strong light.
- 5. Keep away from air conditioners, fans, etc.
- Please use qualified, safety-certified batteries, unqualified batteries or non-rechargeable batteries used may cause fire or explosion.
- 7.If it cannot work after install the battery, please insert the charging cable to charge it and it can be used normally.




Infrared Thermometer User Guide




Model: K3

1.Introduction







2.Specification

- 1. Accuracy: ± 0.2 degrees $\,$ (34 $^{\sim}45\,^{\circ}\!\!\mathrm{C}$, place it in the operating environment for 30 minutes before use)
- 2. Abnormal automatic alarm: flashing +"Di Di" sound
- 3. Automatic measurement: measuring distance 5cm \sim 10cm
- 4. Screen: Digital display
- 5. Charging method: USB charging or battery (18650 Li-ion).
- 6. Install method: nail hook, double-sided adhesive sticking, bracket fixing 7. Environment temperature: 10 $^{\circ}$ $^{\circ}$ $^{\circ}$ (Recommended 15 $^{\circ}$ $^{\circ}$ $^{\circ}$ $^{\circ}$)
- 8. Infrared measuring range: 0 $\sim\!50\,\text{C}$
- 9. Response time: 0.5s
- 10. Input: DC 5V
- 11. Weight: 250g
- 12. Dimensions: 170*115*140mm
- 13. Standby: About one week
- 14. Counting capacity: 999

3.Status Description

- 1. Standby: The red dot in the bottom of the display lights up in turn. (Fig. 1)
- 2. Insufficient power: The horizontal bar lights up in the middle of the display. (Fig. 2)
- 3. Normal temperature: Flashing green lights and alarm 'Di'. (Fig. 3)



Fig. 1



Fig. 2



4. Abnormal temperature: Flashing red lights and alarm 'Di Di'. (Fig. 4)

- 5. Default (bod:object mode)
 - 'Lo': Ultra-low temperature alarm. (Fig.5)
 - 'HI': Ultra-high temperature alarm.(Fig. 6)



Fig. 4



Fig. 5



Fig. 6

4.Operation Instruction

1. Temperature measurement: Front of the thermometer and approach it within 5-10 cm. (Fig. 7)






Fig. 7

- 2. Mode switching: There is a small hole on the back of the device (Fig. 8). You can use a 3mm diameter screwdriver to insert the hole and then press the button
- (1) Temperature unit: Press 'mode switch hole' then select 'C' or 'F' (Fig.9, 10) C: Celsius F: Fahrenheit







Fig. 8

Fig. 9